

Cooking using the electric induction stove

1. Switching the stove on

Assuming the big *right* white switch under the sink is switched on, there is a LED lit by the *key* symbol on the stove. This way the stove is locked. Unlock it by touching the symbol for a few seconds. After about 30 seconds of inactivity, the stove locks itself.

To switch the stove on, touch the ON/OFF symbol for a few seconds. Two zeros are lit now, one for the top plate and one for the bottom plate. After about 30 seconds of inactivity, the stove switches itself off.

2. Cooking

Adjust the power by touching the symbols + and – for the respective plate. If there is a pot on the plate, the number is lit and the plate is working. If there isn't a pot or the pot is not suitable for electric induction stoves, the number flashes and the plate is not working. The plate can be switched off either by removing the pot or by touching both the + and – symbols simultaneously.

Should the temperature of the plate exceed 60°C, a letter H is displayed after the plate has been switched off. This only indicates that the plate is hot; it is no longer working. Only pots with ferromagnetic bottom can be used for cooking on this stove. All the pots and pans in our kitchen meets this requirement.

3. Cooking with timing

It is possible to set the timer for the stove.

- Switch the stove on.
- Touch the + symbol on the timer in the middle of the stove. Both plates display a letter *t*.
- Touch the + symbol for the stove you intend to use. Zeros appear on all the displays.
- Set the timer. The number displays minutes. After that, the stove switches off automatically.
- Set the power for the plate you intend to use. The cooking is started.
- The timer displays the remaining time.
- When the time runs out, two zeros flash on the timer display along with sound indication. Both can be switched off by touching + and – simultaneously.
- Finally, switch the stove off by touching the ON/OFF symbol.

Enjoy your meal.

Jana and Dalibor Bednář, mobile: +420 602 531 763